


To access the base mounting holes in Series A15 UniSlides, you need to remove the end bearing block, slider and knob from the base.



**Remove set screw  
with 5/64 hex wrench**



**Remove 2 screws  
securing End Bearing Block**



**Pull End Block,  
Slider, and lead screw  
from base**



**Mount base and reverse  
process**

When reassembling, be sure to center the end bearing block and collar.