

## KEYCODES for Metronics QC100

(each command below is case sensitive and MUST be terminated with a carriage return)

COMMAND	QC100 Front Panel Key Name
KEY1	Left Wide Key
KEY2	Right Wide Key
KEY3	First Axis
KEY4	Second Axis
KEY5	Third Axis
KEY6	Fourth Axis
KEY7	Left Arrow
KEY8	Up Arrow
KEY9	Right Arrow
KEY10	Down Arrow
KEY11	Soft Key 1
KEY12	Soft Key 2
KEY13	Soft Key 3
KEY14	Soft Key 4
KEY15	Soft Key 5
KEY16	Print
KEY21	0
KEY22	1
KEY23	2
KEY24	3
KEY25	4
KEY26	5
KEY27	6
KEY28	7
KEY29	8
KEY30	9
KEY31	.(decimal point)
KEY32	+/-
KEY33	Enter
KEY34	Finish
KEY35	Cancel
KEY36	Quit
KEY44	Power