Velmex Rotary Table Motor Attachment

READ BEFORE PROCEEDING



- If you receive as a new unit, the worm adjustment has already been done at the factory. Please do not attempt to adjust again.
- If installing a motor on the unit, it is recommended the motor have two flats at 90° angles or it will be difficult to remove, if necessary, in the future.

To attach a motor to a Velmex Rotary Table:

Attaching Instructions

Refer to Diagram 1

- 1. Remove four bolts in motor block.
- 2. Remove reg plug that covers motor coupling access.
 - Set screw should be visible
- 3. Look in motor shaft opening to locate the two set screws. (The screws are set at 90°.) This determines where the flats on the motor shaft are positioned.
- 4. Mount motor with the flats positioned against the set screws.
- 5. Reposition and tighten the four motor mounting screws.

Refer to Diagram 2

- 6. Tighten the one set screw that should be visible through the motor coupling access.
- 7. Run motor to move 2nd set screw in place so that it is visible in the motor coupling access.
- 8. Tighten 2nd set screw.
- 9. Replace motor coupling access plug.






DIAGRAM 1




DIAGRAM 2



Velmex, Inc. 7550 State Routes 5 & 20 Bloomfield, NY 14469-9389

TF:	1.800.642.6446
P:	+1.585.657.6151
F:	+1.585.657.6153

www.velmex.com info@velmex.com

Positioning Systems for Science and Industry

Page 1

Document # B48RotaryMotorMount