



VXM Stepping Motor Controller

Errata for VXM Firmware Versions 1.25, 1.26, 1.27, and 1.30

NOTE: This information is only pertinent for users who are attempting to produce arcs or circles with VXMs in Master/Slave configurations

Appendix G Complex Profiles & Coordinated Motion

Master/Slave Associated Programs

Issue:

Slave VXM will erase program 0 after first run.

Work Around:

Do not use "PMAx" command with x=0, and do not send data to Slave's program 0 with "[]"

NOTE: This issue has been resolved in firmware version 1.31

Contact Information

By Phone: 585-657-6151 and 800-642-6446
By Fax: 585-657-6153
Email: info@velmex.com
On the Internet: www.velmex.com and www.bislide.com
By mail: Velmex, Inc.
7550 State Route 5 & 20
Bloomfield, NY 14469 USA