

;Example Name: AutoReverse

;Description:

- ; 1.) VXM On-Line WITH Echo OFF
- ; 2.) Change To AND Clear Program 0
- ; 3.) Set Motor 1 Speed (Normal Power) = 2000
- ; 4.) Set Loop Marker To Current Location in Program 0
- ; 5.) Motor 1 Move 2000
- ; 6.) Pause Seconds = 1
- ; 7.) Motor 1 Move - 2000
- ; 8.) Loop To Program Start OR Last Known Loop Marker Continuously
- ; 9.) Run Program

;Actual Script seen below

```
;
F,          ;VXM On-Line WITH Echo OFF
PM-0,      ;Change To AND Clear Program 0
S1M2000,   ;Set Motor 1 Speed (Normal Power) = 2000
LM0,       ;Set Loop Marker To Current Location in Program 0
I1M2000,   ;Motor 1 Move 2000
P10,       ;Pause Seconds = 10
I1M-2000,  ;Motor 1 Move - 2000
L0,        ;Loop To Program Start OR Last Known Loop Marker Continuously
R
```